


LENGTH

For determining the length, using a steel tape measure, measure along the back of the pew seat from inside end to inside end.

If the pew has a center divider, measure each section separately from the pew end to the divider.

Record the length to the nearest one eighth inch.



WIDTH

1. When there is a small radius at the front edge, measure from the back corner of the seat to the start of the radius at the front edge.

2. When there is a large radius at the front edge, measure from the back corner of the seat to half way down the radius at the front edge.

3. Customer advises their preference.

